


BASIC TWIN ALTERNATOR CHARGING CIRCUIT



Extreme 4x4 Ltd does not accept any responsibility for parts, which are not fitted correctly.

Always drive your vehicle according to the prevailing conditions and your own driving ability.